

LS-KR0325

SAFETY INSTRUCTIONS

EN

Before using your appliance for the first time, read the booklet carefully and keep it in a safe place. Do not use the appliance if the power cord or plug is damaged. The power cord must be replaced by the manufacturer, its after-sales service or similarly qualified persons in order to avoid a hazard. The appliance must not be immersed in water or any other liquid. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning. Never touch the moving parts with your fingers; always use the accessories provided with the appliance or switch it off then unplug it. Your appliance is only intended for household culinary use, inside the home and at an altitude below 2000 m. It has not been designed to be used in the following circumstances, which are

not cover by the warranty: in kitchen areas reserved for staff in shops, offices and other professional environments, on farms, by clients of hotels, motels and other residential environments and in guest rooms or similar accommodation. Refer to the instructions for initial and regular cleaning of surfaces in contact with foodstuff, and for cleaning and maintenance of your appliance. Refer to the user manual for recipes, speed settings, and for safe usage. This appliance must not be used for more than 2 minutes.

Attention, in case of unintended use of this device, there is a risk of injury !

Children should be supervised to ensure they do not play with the appliance and do not use it as a toy. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or lack of experience

and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

RECYCLING



Environment protection first!

- ① Your appliance contains valuable materials which can be recovered or recycled.
- ➡ Leave it at a local civic waste collection point.

안전 지침

처음 사용하기 전에 사용 설명서를 꼼꼼히 읽고 안전한 곳에 보관하십시오. 전원 코드 또는 플러그가 손상된 경우 제품을 사용하지 마십시오. 전원 코드는 제조업체, 공식 서비스 센터 또는 유사한 자격을 갖춘 기술자가 교체해야 하며, 그렇지 않으면 위험할 수 있습니다. 제품을 물이나 다른 액체에 담그지 마십시오. 제품을 사용하지 않을 때나 조립, 분해, 세척 전에 항상 전원에서 분리하십시오. 작동 중인 부품은 절대로 손가락으로 만지지 마십시오. 항상 제품과 함께 제공된 액세서리를 사용하고, 제제품을 끈 후 플러그를 뽑고 조립하십시오. 이 제품은 가정 내 요리 용도로만 사용되며, 2,000m 이하의 고도에서 사용하도록 설계되었습니다. 다음과 같은 경우에는 사용이 권장되지 않으며, 이로 인한 손상은 보증 대상에 포함되지 않습니다. 상점, 사무실 및 기타 전문 환경의 직원 전용 주방 농장, 호텔, 모텔 및 기타 숙박 시설에서 고객이 사용하는 경우 게스트룸 또는 유사한 숙박 시설 식품과 접촉하는 표면의 초기 및 정기적인 세척 방법과 제품의 유지 관리 방법은 사용 설명서를 참고하십시오. 레시피, 속도 설정 및 안전한

사용법은 사용자 설명서를 확인하십시오. 이 제품은 2분 이상 연속으로 사용해서는 안 됩니다.

주의: 본 기기를 잘못 사용할 경우 부상을 입을 수 있습니다! 어린이가 제품을 가지고 놀거나 장난감처럼 사용하지 않도록 반드시 보호자의 감독이 필요합니다. 이 제품은 신체적, 감각적, 정신적 능력이 제한되었거나 경험과 지식이 부족한 사람이 사용할 수 있도록 설계되지 않았습니다. 다만, 안전을 책임지는 사람이 적절한 감독을 하거나 사용법을 충분히 설명한 경우에는 사용이 가능합니다.

재활용



환경을 보호합시다!

- ① 본 제품에는 재활용할 수 있는 소재들이 있습니다.
- ② 해당 지역 분리 수거함에 배출하시기 바랍니다.

Ref. 1520017724