

Tefal®

EN • SAFETY INSTRUCTIONS

KO • 안전 주의 사항

Read the instructions before use to avoid any danger due to misuse.

SAFETY INSTRUCTIONS

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not attempt to recharge non-rechargeable batteries.
- Do not mix new and used batteries or different types of batteries.
- Ensure that the polarity is correct when inserting the batteries.
- Empty batteries must be removed from the device and disposed of in a safe manner.
- Remove batteries from a device if it is not intended to be used for a long period.
- Do not short-circuit the power supply terminal.

GUARANTEE

Your appliance is designed for use in the home only.

It should not be used for professional purposes.

The guarantee becomes null and void in the case of improper usage.

ENVIRONMENT PROTECTION FIRST!



Your appliance contains valuable materials which can be recovered or recycled. Leave it at a local civic waste collection point.

Never throw used battery into the dustbin: consider them as chemical residue. Take them to a recognised collection point.

These instructions are also available on our website www.tefal.com

KO

안전한 사용을 위해 제품 사용 전, 안전 주의 사항을 주의 깊게 읽어주십시오.

안전 주의 사항

- 8세 이상의 어린이와 신체적인 감각 및 정신적인 능력이 미약하거나 경험과 지식이 풍부하지 않은 성인이 이 제품을 사용하기 위해서는 제품 사용과 관련하여 안전하게 사용할 수 있도록 지시 사항을 충분히 숙지한 사람의 도움을 받아야 합니다. 어린이가 제품을 가지고 놀지 못하도록 보호해 주시기 바랍니다. 세척 및 제품 유지 보수 작업의 경우 보호자 없이 어린이 혼자 하지 않도록 관리해 주십시오.
- 이 제품은 신체적인 감각 및 정신적인 능력이 미약하거나 경험과 지식이 풍부하지 않은 사람 (어린이 포함)이 보호자의 감독이나 제품 사용에 대한 안전 주의 사항 및 사용 설명서를 충분히 숙지한 사람의 도움없이 사용하지 않습니다.
- 재충전 불가능한 배터리로 충전을 시도하지 마십시오.
- 새 배터리와 사용된 배터리를 함께 사용하거나 다른 종류의 배터리들을 함께 사용하지 마십시오.
- 배터리를 넣을 때, 양 극이 알맞게 위치 되었는지 확인하십시오.
- 사용이 끝난 배터리는 반드시 기기에서 제거한 뒤에 안전하게 폐기하십시오.
- 장기간 제품 미사용 시, 제품의 배터리를 제거해 주십시오.
- 전원 공급 단자를 합선하지 마십시오.

품질 보증

이 제품은 가정용으로 제작되었으며, 상업용 또는 부적절하게 사용된 경우 당사의 품질보증 혜택을 받으실 수 없습니다.

환경 보호



이 제품은 재활용이 가능한 부속품들을 포함하고 있습니다. 보호를 위해 분리 수거해주시시오.

사용된 배터리를 쓰레기통에 버리지 마십시오: 화학 폐기물로 처리하십시오. 지정된 장소에 버리십시오.

제품의 사용 설명서는 테팔 홈페이지에서도 확인하실 수 있습니다. www.tefal.com