

FR Linje attentamente leEmpio è progettato secondo le norme vigenti in vigore per quanto riguarda le precauzioni da adottare contro ogni rischio di lesioni.

CONSEILS DE SECURITE

• Pour votre sécurité, cet appareil est conforme aux normes et réglementations applicables (Directives Basses Tension, Compatibilité Electromagnétique, Environnement, ...).
• Les accessoires de l'appareil destinés spécialement à cet usage, pendant l'utilisation, évitent le contact avec le peau. Assurez-vous que le cordon d'alimentation soit toujours en contact avec les parties chaudes de l'appareil.
• Vérifiez que la tension de votre installation électrique corresponde à celle de votre appareil. Toute erreur de branchement peut causer des dommages irréversibles non couverts par la garantie.

• **Pour une protection supplémentaire, l'installation d'un dispositif à courant résiduel (RCD) ayant un courant de fonctionnement résiduel nominal n'excédant pas 30 mA est conseillée dans le circuit électrique alimentant la salle de bain. Demandez conseil à l'installateur.**
• Risque de brûlure. Garez l'appareil hors de portée des jeunes enfants, en particulier pendant l'utilisation et le refroidissement.
• Lorsque l'appareil est connecté à l'alimentation, ne le laissez jamais sans surveillance. Placez toujours l'appareil avec le support, stable et sur une surface plane, stable et résistante à la chaleur.
• L'installation de l'appareil et son utilisation doit toujours être conforme aux normes en vigueur dans votre pays.

• **ATTENTION: ne pas utiliser cet appareil près des baignoires, douches, lavabos ou autres récipients contenant de l'eau.**
• Lorsque l'appareil est utilisé dans une salle de bain, débranchez-le après usage, car la proximité de l'eau représente un danger, même lorsque l'appareil est éteint.
• Pour les autres pays non soumis à la réglementation de l'UE (C) ce type d'appareil n'est pas prévu pour être utilisé par des personnes à capacités physiques, sensorielles ou mentales réduites, ou des personnes dépourvues d'expérience ou de connaissances, s'ils ont peur de bénéficier, par l'intermédiaire d'une personne responsable de leur sécurité, d'une surveillance ou d'instructions particulières concernant l'utilisation de l'appareil.

• **Pour les pays soumis à la réglementation de l'UE (C) ce type d'appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience et de connaissances, s'ils ont reçu un encadrement ou des instructions concernant l'utilisation de l'appareil en toute sécurité et comprennent les risques encourus. Les enfants ne doivent pas jouer avec l'appareil. Les enfants ne doivent ni nettoyer l'appareil ni s'occuper de son entretien sans surveillance. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.**

• **Si le câble d'alimentation est endommagé, il doit être remplacé par le fabricant, son service après vente ou des personnes de qualification similaire afin d'éviter un danger.**

• **N'utilisez pas votre appareil et contactez un Centre Service Agréé si le service après est tombé, s'il ne fonctionne pas normalement.**

L'appareil est équipé d'un système de sécurité thermique. En cas de surchauffe (à titre d'exemple à l'encrassement de la grille anti-éclaboussure) l'appareil s'arrête automatiquement et continue le SAV. L'appareil doit être débranché, avant l'intervention de l'entretien, en cas d'absence de fonctionnement, dès que vous avez terminé de l'utiliser, si vous ne pouvez plus le réparer, même momentanément.

• **Ne pas utiliser le cordon et le câble endommagés.**
• Ne pas immerger ni passer sous l'eau, même pour le nettoyage.
• Ne pas laisser l'appareil et ses accessoires mouillés.
• Ne pas tenter de la bouillir ou est chaud, mais pas la laisser.
• Ne pas débrancher le cordon de l'appareil, même en touchant le cordon.
• Ne pas utiliser de prolongateur électrique.

• Ne pas nettoyer avec des produits abrasifs ou corrosifs.
• Ne pas utiliser sur température inférieure à 5 °C et supérieure à 35 °C.

GARANTIE
Votre appareil est destiné à un usage domestique seulement. Il ne peut être utilisé à des fins professionnelles. La garantie devient nulle et invalide en cas d'utilisation commerciale.

PARTICIPONS A LA PROTECTION DE L'ENVIRONNEMENT!

• Vérifiez avoir content de nombreux matériaux recyclables ou recyclés.
• Contactez le fabricant pour plus de renseignements sur les services après-vente agréés pour ce traitement spécial écológico.
• Ces instructions sont également disponibles sur notre site internet www.rowenta.com

EN Read the instructions carefully as well as the safety guidelines before use.
• Do not use the power cord and cable if damaged. Do not immerse the appliance in water, even for cleaning purposes.
• Do not attempt to boil or use while hot. Do not touch the power cord or plug.
• Do not use an extension cord.
• Do not clean the appliance with abrasive or corrosive products.
• Do not use at temperatures below 0 °C and above 35 °C.

GARANTIE
Your appliance is designed for household use only. It should not be used for professional purposes. The guarantee becomes null and void in the case of commercial use.

PARTICIPONS A LA PROTECTION DE L'ENVIRONNEMENT!
Vérifiez avoir content de nombreux matériaux recyclables ou recyclés.

• Contactez le fabricant pour plus de renseignements sur les services après-vente agréés pour ce traitement spécial écológico.

Ces instructions sont également disponibles sur notre site internet www.rowenta.com

EN Read the instructions carefully as well as the safety guidelines before use.

SAFETY
• For your safety, this appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environment, ...).
• The appliance's accessories become very hot during use. Avoid contact with the skin. Make sure that the supply cord never comes into contact with the hot parts of the appliance.
• Check that the voltage of your electricity supply matches the voltage of your appliance. Any error when connecting the appliance can cause irreparable harm, not covered by the guarantee.

• **For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask for installer for advice.**
• Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down. When the appliance is connected to the power supply, never leave it unattended.
• Always place the appliance with the stand, stable and on a heat-resistant, stable flat surface.
• The installation of the appliance and its use must always comply with the standards in force in your country.

• **WARNING: do not use this appliance near bathtubs, showers, basins or other vessels containing water.**
• When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

• For other countries not subject to EU regulations: This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
• For countries subject to EU regulations (CE) : This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,
• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

WAARSCHUWING: gebruik dit apparaat niet in de buurt van badkuipen, douches, wasbakken of andere water bevattende reservoirs.

• **Wanneer het apparaat gebruikt wordt in een badkamer, haal dan de stekker na gebruik uit het stopcontact, aangezien de nabijheid van water gevaar oplevert zelfs wanneer het apparaat is uitgeschakeld.**

• **WAARSCHUWING:** gebruik dit apparaat niet in de buurt van badkuipen, douches, wasbakken of andere water bevattende reservoirs.

• **Wanneer het apparaat gebruikt wordt in een badkamer, haal dan de stekker na gebruik uit het stopcontact, aangezien de nabijheid van water gevaar oplevert zelfs wanneer het apparaat is uitgeschakeld.**

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,

• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

GUARANTEE
Your appliance is designed for use in the home only. It should not be used for professional purposes. The guarantee becomes null and void in the case of improper use.

ENVIRONMENT PROTECTION FIRST!
• Check that you have content of valuable materials which can be recovered or recycled.
• Leave it at a local waste collection point.

These instructions are also available on our website www.rowenta.com

DE Lesen Sie vor der Inbetriebnahme die Gebrauchsanweisung und die Sicherheitsvorschriften sorgfältig durch.

SICHERHEITSHINWEISE
• Lesen Sie die Gebrauchsanweisung sorgfältig vor der ersten Inbetriebnahme Ihres Gerätes/durch. Eine unsachgemäße Bedienung verbunden mit der Benutzung des Gerätes birgt erhebliche Verletzungsrisiken.
• Verifizieren Sie die Angaben zur Leistung des Gerätes vor der ersten Inbetriebnahme.
• Achten Sie bei der Montage auf die im Kapitel "Anschließen des Gerätes" angegebenen Angaben.
• Lesen Sie die Bedienungsanleitung des Gerätes vor der ersten Inbetriebnahme sorgfältig durch.
• Lesen Sie die Bedienungsanleitung des Gerätes mit der Spannung ihrer Elektroinstallation übereinstimmend. Ein fehlerhafter Anschluss kann irreparable Schäden hervorrufen, die nicht von der Garantie abgedeckt sind.

• **Zum zusätzlichen Schutz sollte das Gerät an den Stromkreis des Badezimmers mit einer Fehlerstrom-Schutzeinrichtung für Wechselstrom mit 30 mA Nennfehlerstrom angeschlossen werden. Lassen Sie sich von Ihrem Elektroinstallateur beraten.**
• Risiko de brûlures. Gardez l'appareil hors de portée des jeunes enfants, en particulier pendant l'utilisation et le refroidissement.
• Lorsque l'appareil est connecté à l'alimentation, ne le laissez jamais sans surveillance. Placez toujours l'appareil avec le support, stable et sur une surface plane, stable et résistante à la chaleur.
• L'installation de l'appareil et son utilisation doit toujours être conforme aux normes en vigueur dans votre pays.

• **ATTENTION: ne pas utiliser cet appareil près des baignoires, douches, lavabos ou autres récipients contenant de l'eau.**
• Lorsque l'appareil est utilisé dans une salle de bain, débranchez-le après usage, car la proximité de l'eau représente un danger, même lorsque l'appareil est éteint.
• Pour les autres pays non soumis à la réglementation de l'UE (C) ce type d'appareil n'est pas prévu pour être utilisé par des personnes à capacités physiques, sensorielles ou mentales réduites, ou des personnes dépourvues d'expérience ou de connaissances, s'ils ont peur de bénéficier, par l'intermédiaire d'une personne responsable de leur sécurité, d'une surveillance ou d'instructions particulières concernant l'utilisation de l'appareil.

• **Pour les pays soumis à la réglementation de l'UE (C) ce type d'appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience et de connaissances, s'ils ont reçu un encadrement ou des instructions concernant l'utilisation de l'appareil en toute sécurité et comprennent les risques encourus. Les enfants ne doivent pas jouer avec l'appareil. Les enfants ne doivent ni nettoyer l'appareil ni s'occuper de son entretien sans surveillance. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.**

• **Si le câble d'alimentation est endommagé, il doit être remplacé par le fabricant, son service après vente ou des personnes de qualification similaire afin d'éviter un danger.**

• **N'utilisez pas votre appareil et contactez un Centre Service Agréé si le service après est tombé, s'il ne fonctionne pas normalement.**

L'appareil est équipé d'un système de sécurité thermique. En cas de surchauffe (à titre d'exemple à l'encrassement de la grille anti-éclaboussure) l'appareil s'arrête automatiquement et continue le SAV. L'appareil doit être débranché, avant l'intervention de l'entretien, en cas d'absence de fonctionnement, dès que vous avez terminé de l'utiliser, si vous ne pouvez plus le réparer, même momentanément.

• **Ne pas utiliser le cordon et le câble endommagés.**
• Ne pas immerger ni passer sous l'eau, même pour le nettoyage.
• Ne pas laisser l'appareil et ses accessoires mouillés.
• Ne pas tenter de la bouillir ou est chaud, mais pas la laisser.
• Ne pas débrancher le cordon de l'appareil, même en touchant le cordon.
• Ne pas utiliser de prolongateur électrique.

• Ne pas nettoyer avec des produits abrasifs ou corrosifs.
• Ne pas utiliser sur température inférieure à 5 °C et supérieure à 35 °C.

GARANTIE
Votre appareil est destiné à un usage domestique seulement. Il ne peut être utilisé à des fins professionnelles. La garantie devient nulle et invalide en cas d'utilisation commerciale.

PARTICIPONS A LA PROTECTION DE L'ENVIRONNEMENT!
Vérifiez avoir content de nombreux matériaux recyclables ou recyclés.

• Contactez le fabricant pour plus de renseignements sur les services après-vente agréés pour ce traitement spécial écológico.

Ces instructions sont également disponibles sur notre site internet www.rowenta.com

EN Read the instructions carefully as well as the safety guidelines before use.

SAFETY
• For your safety, this appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environment, ...).
• The appliance's accessories become very hot during use. Avoid contact with the skin. Make sure that the supply cord never comes into contact with the hot parts of the appliance.
• Check that the voltage of your electricity supply matches the voltage of your appliance. Any error when connecting the appliance can cause irreparable harm, not covered by the guarantee.

• **For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask for installer for advice.**
• Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down. When the appliance is connected to the power supply, never leave it unattended.
• Always place the appliance with the stand, stable and on a heat-resistant, stable flat surface.
• The installation of the appliance and its use must always comply with the standards in force in your country.

• **WARNING: do not use this appliance near bathtubs, showers, basins or other vessels containing water.**
• When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

• For other countries not subject to EU regulations: This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
• For countries subject to EU regulations (CE) : This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,

• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

WAARSCHUWING: gebruik dit apparaat niet in de buurt van badkuipen, douches, wasbakken of andere water bevattende reservoirs.

• **Wanneer het apparaat gebruikt wordt in een badkamer, haal dan de stekker na gebruik uit het stopcontact, aangezien de nabijheid van water gevaar oplevert zelfs wanneer het apparaat is uitgeschakeld.**

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,

• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

GUARANTEE
Your appliance is designed for use in the home only. It should not be used for professional purposes. The guarantee becomes null and void in the case of improper use.

ENVIRONMENT PROTECTION FIRST!
• Check that you have content of valuable materials which can be recovered or recycled.
• Leave it at a local waste collection point.

These instructions are also available on our website www.rowenta.com

ES De stekker niet uit het stopcontact halen door aan het snoer te trekken, maar alleen via de stekker.

SICHERHEITSHINWEISE
• Lesen Sie die Gebrauchsanweisung sorgfältig vor der ersten Inbetriebnahme Ihres Gerätes/durch. Eine unsachgemäße Bedienung verbunden mit der Benutzung des Gerätes birgt erhebliche Verletzungsrisiken.
• Verifizieren Sie die Angaben zur Leistung des Gerätes vor der ersten Inbetriebnahme.
• Achten Sie bei der Montage auf die im Kapitel "Anschließen des Gerätes" angegebenen Angaben.
• Lesen Sie die Bedienungsanleitung des Gerätes vor der ersten Inbetriebnahme sorgfältig durch.
• Lesen Sie die Bedienungsanleitung des Gerätes mit der Spannung ihrer Elektroinstallation übereinstimmend. Ein fehlerhafter Anschluss kann irreparable Schäden hervorrufen, die nicht von der Garantie abgedeckt sind.

• **Zum zusätzlichen Schutz sollte das Gerät an den Stromkreis des Badezimmers mit einer Fehlerstrom-Schutzeinrichtung für Wechselstrom mit 30 mA Nennfehlerstrom angeschlossen werden. Lassen Sie sich von Ihrem Elektroinstallateur beraten.**
• Risiko de brûlures. Gardez l'appareil hors de portée des jeunes enfants, en particulier pendant l'utilisation et le refroidissement.
• Lorsque l'appareil est connecté à l'alimentation, ne le laissez jamais sans surveillance. Placez toujours l'appareil avec le support, stable et sur une surface plane, stable et résistante à la chaleur.
• L'installation de l'appareil et son utilisation doit toujours être conforme aux normes en vigueur dans votre pays.

• **ATTENTION: ne pas utiliser cet appareil près des baignoires, douches, lavabos ou autres récipients contenant de l'eau.**
• Lorsque l'appareil est utilisé dans une salle de bain, débranchez-le après usage, car la proximité de l'eau représente un danger, même lorsque l'appareil est éteint.
• Pour les autres pays non soumis à la réglementation de l'UE (C) ce type d'appareil n'est pas prévu pour être utilisé par des personnes à capacités physiques, sensorielles ou mentales réduites, ou des personnes dépourvues d'expérience ou de connaissances, s'ils ont peur de bénéficier, par l'intermédiaire d'une personne responsable de leur sécurité, d'une surveillance ou d'instructions particulières concernant l'utilisation de l'appareil.

• **Pour les pays soumis à la réglementation de l'UE (C) ce type d'appareil peut être utilisé par des enfants âgés de 8 ans et plus et des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou un manque d'expérience et de connaissances, s'ils ont reçu un encadrement ou des instructions concernant l'utilisation de l'appareil en toute sécurité et comprennent les risques encourus. Les enfants ne doivent pas jouer avec l'appareil. Les enfants ne doivent ni nettoyer l'appareil ni s'occuper de son entretien sans surveillance. Il convient de surveiller les enfants pour s'assurer qu'ils ne jouent pas avec l'appareil.**

• **Si le câble d'alimentation est endommagé, il doit être remplacé par le fabricant, son service après vente ou des personnes de qualification similaire afin d'éviter un danger.**

• **N'utilisez pas votre appareil et contactez un Centre Service Agréé si le service après est tombé, s'il ne fonctionne pas normalement.**

L'appareil est équipé d'un système de sécurité thermique. En cas de surchauffe (à titre d'exemple à l'encrassement de la grille anti-éclaboussure) l'appareil s'arrête automatiquement et continue le SAV. L'appareil doit être débranché, avant l'intervention de l'entretien, en cas d'absence de fonctionnement, dès que vous avez terminé de l'utiliser, si vous ne pouvez plus le réparer, même momentanément.

• **Ne pas utiliser le cordon et le câble endommagés.**
• Ne pas immerger ni passer sous l'eau, même pour le nettoyage.
• Ne pas laisser l'appareil et ses accessoires mouillés.
• Ne pas tenter de la bouillir ou est chaud, mais pas la laisser.
• Ne pas débrancher le cordon de l'appareil, même en touchant le cordon.
• Ne pas utiliser de prolongateur électrique.

• Ne pas nettoyer avec des produits abrasifs ou corrosifs.
• Ne pas utiliser sur température inférieure à 5 °C et supérieure à 35 °C.

GARANTIE
Votre appareil est destiné à un usage domestique seulement. Il ne peut être utilisé à des fins professionnelles. La garantie devient nulle et invalide en cas d'utilisation commerciale.

PARTICIPONS A LA PROTECTION DE L'ENVIRONNEMENT!
Vérifiez avoir content de nombreux matériaux recyclables ou recyclés.

• Contactez le fabricant pour plus de renseignements sur les services après-vente agréés pour ce traitement spécial écológico.

Ces instructions sont également disponibles sur notre site internet www.rowenta.com

EN Read the instructions carefully as well as the safety guidelines before use.

SAFETY
• For your safety, this appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environment, ...).
• The appliance's accessories become very hot during use. Avoid contact with the skin. Make sure that the supply cord never comes into contact with the hot parts of the appliance.
• Check that the voltage of your electricity supply matches the voltage of your appliance. Any error when connecting the appliance can cause irreparable harm, not covered by the guarantee.

• **For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask for installer for advice.**
• Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down. When the appliance is connected to the power supply, never leave it unattended.
• Always place the appliance with the stand, stable and on a heat-resistant, stable flat surface.
• The installation of the appliance and its use must always comply with the standards in force in your country.

• **WARNING: do not use this appliance near bathtubs, showers, basins or other vessels containing water.**
• When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

• For other countries not subject to EU regulations: This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
• For countries subject to EU regulations (CE) : This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,

• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

GUARANTEE
Your appliance is designed for use in the home only. It should not be used for professional purposes. The guarantee becomes null and void in the case of improper use.

ENVIRONMENT PROTECTION FIRST!
• Check that you have content of valuable materials which can be recovered or recycled.
• Leave it at a local waste collection point.

These instructions are also available on our website www.rowenta.com

EN Read the instructions carefully as well as the safety guidelines before use.

SAFETY
• For your safety, this appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environment, ...).
• The appliance's accessories become very hot during use. Avoid contact with the skin. Make sure that the supply cord never comes into contact with the hot parts of the appliance.
• Check that the voltage of your electricity supply matches the voltage of your appliance. Any error when connecting the appliance can cause irreparable harm, not covered by the guarantee.

• **For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask for installer for advice.**
• Burn hazard. Keep appliance out of reach from young children, particularly during use and cool down. When the appliance is connected to the power supply, never leave it unattended.
• Always place the appliance with the stand, stable and on a heat-resistant, stable flat surface.
• The installation of the appliance and its use must always comply with the standards in force in your country.

• **WARNING: do not use this appliance near bathtubs, showers, basins or other vessels containing water.**
• When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.

• For other countries not subject to EU regulations: This appliance is not intended for use by persons including children with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
• For countries subject to EU regulations (CE) : This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,

• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

WAARSCHUWING: gebruik dit apparaat niet in de buurt van badkuipen, douches, wasbakken of andere water bevattende reservoirs.

• **Wanneer het apparaat gebruikt wordt in een badkamer, haal dan de stekker na gebruik uit het stopcontact, aangezien de nabijheid van water gevaar oplevert zelfs wanneer het apparaat is uitgeschakeld.**

• **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.**

• **Stop using your appliance and contact an Authorised Service Centre if:**
• your appliance has fallen,

• it does not work correctly.
• The appliance is equipped with a heat-sensitive safety device: in the event of overheating (for example if the power plug is blocked), the dryer will stop automatically, contact the After-Sales Service.
• The appliance must not be unplugged before cleaning procedures: if it is not working correctly, as soon as you have finished using it, it may become hot, even momentarily.

• **Do not immerse the plug and/or landing water, even for cleaning purposes.**
• Do not hold with damp hands.
• Do not hold the appliance by the casing, which is hot, but by the handle.
• Do not unscrew the appliance or other pull-out by the plug.
• Do not use an electrical extension cord.
• Do not clean with abrasive or corrosive products.
• Do not use at temperatures below 0°C and above 35°C.

GUARANTEE
Your appliance is designed for use in the home only. It should not be used for professional purposes. The guarantee becomes null and void in the case of improper use.

ENVIRONMENT PROTECTION FIRST!
• Check that you have content of valuable materials which can be recovered or recycled.
• Leave it at a local waste collection point.

These instructions are also available on our website www.rowenta.com

PT Este aparelho destina-se ao uso doméstico. Não deve ser utilizado para fins profissionais. A garantia torna-se nula e inválida em caso de utilização incorreta.

GARANTIA
Este aparelho é destinado exclusivamente ao uso doméstico. Não deve ser utilizado a scopi professionali. La garanzia diventa nulla e invalida in caso di uso non corretto.
La garanzia non è valida in caso di utilizzo scorretto.

CONTRIBUIAMO ALLA PROTEZIONE DELL'AMBIENTE!
• Controllare il contenuto dei materiali riciclabili e riciclabili.
• Lasciarlo in un punto di raccolta, o in un centro assistenza autorizzato affinché venga effettuato l'uso corretto del prodotto.

