

Moulinex®


subito

NC00024372 • 05/2011



www.moulinex.com

Moulinex®

subito




www.moulinex.com





* Selon modèle - Afhankelijk van de model - Je nach Modell - Depending on model - Segundo il modello - Según modelo - Consoante o modelo - Ανάλογα με το μοντέλο - Modele göre - Afhængigt af modellen - Beroende på modell - Avhengig av modell - Mallista riippuen - Ovisno o modelu - Uzavisnosti od modela - Modeltöl fuggően - Според модела - Odvisno od modela - Zależnie od modelu - Podle typu - Podľa typu - Bizonyos típusoknál - В зависимости от модели - Залежно від моделі - În funcție de model - Vastavalt mudelitele - Atkaribā no modeļa - Pagal modelius - بحسب مدل - حسب الموديل

1 FIRST USE





2 TOASTING




3 STOP

stop








4 BUN WARMER*





* Selon modèle - Afhankelijk van de model - Je nach Modell - Depending on model - Secondo il modello - Según modelo - Consoante o modelo - Ανάλογα με το μοντέλο - Modele göre - Afhængigt af modellen - Beroende på modell - Avhengig av modell - Mallista riippuen - Ovisno o modelu - U zavisnosti od modela - Modeltől függően - Според модела - Odvisno od modela - Zależnie od modelu - Podle typu - Podla typu - Bázonyos típusoknál - В зависимости от модели - Залежно від моделі - În funcție de model - Vastavalt mudelitele - Atkaribā no modeļa - Pagal modelius - بر حسب مدل - حسب الموديل.


5 REHEAT



6 DEFROST



7 CLEANING



8 DO NOT

