




EN	User guide
FR	Guide de l'utilisateur
ES	Guía del usuario
PT	Guía del usuario
ZH	使用者指南
CN	使用指南
MS	Panduan pengguna




TURBO SWIFT SILENCE




1.







2.




3.











8.


**AUTO
OFF**




9.



10.



11.



EN Please read carefully the "Safety and use instructions" booklet before first use / **FR** Veuillez lire attentivement le livret "Consignes de sécurité et d'utilisation" avant la première utilisation / **ES** Lea detenidamente el libro «Instrucciones de seguridad y de uso» antes de utilizar el aparato por primera vez / **PT** Leia atentamente o manual «Instruções de segurança e utilização» antes da primeira utilização / **ZH** 首次使用前，請仔細閱讀「安全及使用說明」小冊子 / **CN** 首次使用前請仔細閱讀《安全與使用說明》手冊 / **MS** Sila baca buku kecil "arahan keselamatan dan penggunaan" dengan teliti sebelum penggunaan pertama

EN For more information / **FR** Pour plus d'informations / **ES** Para más información / **PT** Para mais informações / **ZH** 了解詳情 / **CN** 更多信息 / **MS** Untuk mendapatkan maklumat lanjut

www.rowenta.com
www.tefal.com

1820017848/02

