

Easy Fry XL Surface

QUICK START GUIDE

KIT DE DÉMARRAGE RAPIDE - GUÍA RÁPIDA DE INICIO - GUIA DE INÍCIO RÁPIDO -
GUIDA RAPIDA INTRODUTTIVA - ΟΔΗΓΟΣ ΓΡΗΓΟΡΗΣ ΕΚΚΙΝΗΣΗΣ - SNESTARTGIDS



Moulinex

YOUR PRODUCT

VOTRE PRODUIT - TU PRODUCTO - O SEU PRODUTO -
IL TUO PRODOTTO - TO ΠΡΟΪΟΝ - JOUW PRODUCT



Digital touchscreen panel

Écran digital tactile - Pantalla táctil digital - Ecrã tátil digital -
Touch screen digitale - Ψηφιακή οθόνη αφής - Digitaal touchscreen

1 large drawer

1 large cuve - 1 cajón grande - 1 gaveta grande -
1 cassetto grande - 1 μεγάλο συρτάρι - 1 grote lade

PRODUCT INTERFACE

INTERFACE PRODUIT - INTERFAZ DEL PRODUCTO - INTERFACE DO PRODUTO -
INTERFACCIA DEL PRODOTTO - ΠΑΝΕΛ ΠΡΟΪΟΝΤΟΣ - BEDIENINGSSCHERM

10 pre-set programs

10 programmes prédéfinis - 10 programas preestablecidos - 10 programas automáticos -
10 programmi preimpostati - 10 αυτόματα προγράμματα - 10 automatische programma's

Temperature control

Contrôle de la température
Control de temperatura
Controlo da temperatura
Controllo della temperatura
Έλεγχος θερμοκρασίας
Temperatuurregeling

Time control


Contrôle du temps
Control del tiempo
Controlo do tempo
Controllo del tempo
Έλεγχος χρόνου
Tijdscontrole

Start/stop cooking

Lancement/arrêt de cuisson
Inicio/parada de la cocción
Iniciar/parar a cozedura
Avvio/arresto della cottura
Έναρξη/διακοπή μαγειρέματος
Koken starten/stoppen

On/Off device

Marche/arrêt machine
Dispositivo de encendido/apagado
Dispositivo de ligar/desligar
Dispositivo di accensione/
spengimento
Ενεργοποίηση/απενεργοποίηση
συσκευής
Apparaat aan/uit



To change the cooking mode





























Naviguer entre les modes
Para cambiar el modo de cocción
Para alterar o modo de cozedura
Per cambiare la modalità di cottura
Για να αλλάξετε τη λειτουργία μαγειρέματος
De kookstand wijzigen

To switch the light on/off

Pour allumer/éteindre l'éclairage
Para encender y apagar la luz
Para ligar/desligar a luz
Per accendere e spegnere la luce
Για να ανάψετε/σβήσετε το φως
Het licht aan/uit zetten

COOKING GUIDE

GUIDE DE CUISSON - GUÍA DE COCINA - GUIA DE COZEDURA -
GUIDA ALLA COTTURA - ΟΔΗΓΟΣ ΜΑΓΕΙΡΕΜΑΤΟΣ - KOOKGIDS

					SHAKE
POTATOES & FRIES - POMMES DE TERRE ET FRITES - PATATAS Y PATATAS FRITAS - BATATAS E BATATAS FRITAS - ΡΑΤΑΤΕ Ε ΡΑΤΑΤΙΝΕ FRITTE - ΠΑΤΑΤΕΣ & ΤΗΓΑΝΙΤΕΣ ΠΑΤΑΤΕΣ - AARDAPPELEN & FRIET					
	1 kg	35 min	180°C		x 2
MEAT & POULTRY - VIANDE ET VOLAILLES - CARNE Y AVES - CARNE E AVES DE CAPOEIRA - CARNE E POLLAME - ΚΡΕΑΣ & ΠΟΥΛΙ - VLEES & PLUIMVEE					
	6 pieces (875 g)	25 min	180°C		-
	12 pieces (1,5kg)	25 min	200°C		-
	8 pieces	8 min	180°C		-
	10 (125 g / sausage)	25 min	200°C		-
FISH - POISSON - PESCADO - PEIXE - PESCE - ΨΑΡΙ - VIS					
	6 (150 g/piece)	8min	200°C		-
	12 pieces (435 g)	7 min	140°C		-
SNACKS - SNACKS - BOCADILLOS - PETISCOS - SPUNTINI - SNACKS - SNACKS					
	25 pieces (700 g)	15 min	200 °C		-
	750 g	16 min	200 °C		-
	26 cm diameter	10 min	200 °C	FROZEN PIZZA	-
	26 cm diameter	6 min	220 °C		FRESH PIZZA
VEGETABLES - LÉGUMES - VERDURAS - VEGETAIS - ORTAGGI - ΛΑΧΑΝΙΚΑ - GROENTEN					
	600 g	10 min	200 °C		/
	800 g	20 min	180 °C		X 2
BAKING - PÂTISSERIE - COCCIÓN - COZEDURA - COTTURA - BAKING - BAKKERIJ					
	9 - 12 pieces	10 min	180 °C		/
DEHYDRATION - DÉSHYDRATATION - DESHIDRATACIÓN - DESIDRATAÇÃO - DEIDRATAZIONE - ΑΠΟΨΥΞΗ - DEHYDRATIE					
	1 - 2 pieces	70 °C	4 h		/

Easy Fry XL Surface



FOR MORE RECIPE INSPIRATION AND IDEAS, DOWNLOAD THE MOULINEX APP

POUR PLUS D'INSPIRATION ET D'IDÉES DE RECETTES, TÉLÉCHARGEZ L'APPLICATION MOULINEX
PARA MÁS INSPIRACIÓN E IDEAS DE RECETAS, DESCARGA LA APP DE MOULINEX
PARA MAIS INSPIRAÇÃO E IDEIAS DE RECEITAS, DESCARREGUE A APLICAÇÃO MOULINEX
PER ALTRE IDEE E ISPIRAZIONI DI RICETTE, SCARICATE L'APP MOULINEX
ΓΙΑ ΠΕΡΙΣΣΟΤΕΡΗ ΈΜΠΝΕΥΣΗ ΚΑΙ ΙΔΕΕΣ ΓΙΑ ΣΥΝΤΑΓΕΣ, ΚΑΤΕΒΑΣΤΕ ΤΗΝ ΕΦΑΡΜΟΓΗ MOULINEX
DOWNLOAD DE MOULINEX APP VOOR MEER RECEPTINSPIRATIE EN IDEEËN



JOIN THE MOULINEX MOVEMENT!

REJOIGNEZ LE MOUVEMENT MOULINEX! - ÚNETE A LA APP MOULINEX - JUNTE-SE AO MOVIMENTO MOULINEX! -
UNISCITI AL MOVIMENTO MOULINEX! - ΜΠΕΙΤΕ ΣΤΟ ΚΙΝΗΜΑ MOULINEX - DOE MEE MET DE MOULINEX-BEWEGING!



MOULINEX APP



YOUTUBE CHANNEL



MOULINEX
ON INSTAGRAM

POST YOUR RECIPES #EASYFRYFAMILY

POSTEZ VOS RECETTES #EASYFRYFAMILY - PUBLIQUE SUS RECETAS #EASYFRYFAMILY - PUBLIQUE AS SUAS RECEITAS #EASYFRYFAMILY -
PUBBLICA LE TUE RICETTE #EASYFRYFAMILY - ΔΗΜΟΣΙΕΥΣΤΕ ΤΙΣ ΣΥΝΤΑΓΕΣ ΣΑΣ #EASYFRYFAMILY - POST JE RECEPTEN #EASYFRYFAMILY

