


EN

ZH

MS




Mix&Move Blender

8020011826/01



EN : Read safety instructions and booklet carefully before using for the first time.

ZH : 請在第一次使用前仔細閱讀安全說明和手冊。





MS : Baca arahan keselamatan dan buku panduan dengan teliti sebelum menggunakannya untuk kali pertama.







1




2



3



		
	 100g + 150g OF CARROTS OF WATER	30sec
	 90g of dried fig	15sec

			
	✗	✗	✓
	✓	✓	✓
	✓	✗	✗



EN : Warning: Do not process hot liquids (over 70°C/158°F) in the on-the-go bottle.

ZH : 警告: 请勿在便携瓶中处理热液体 (超过 70°C/158°F)。

MS : Jangan kendalikan cecair panas (melebihi 70°C/158°F) dalam botol mudah alih.

EN : *Wait for 2 min between two blending sessions. The ratio of liquid and solid ingredients enabling correct blending depends on the recipe. Ice can be crushed without added water (ice cubes having an edge of 2cm). If your appliance does not work, check it is properly connected to the mains, the power cord is in good condition and the blade holder is assembled with the bottle. If the appliance overheats, unplug and let the appliance cool down to room temperature. Your appliance still does not work? Contact an approved service centre (see the service booklet).

ZH : *在兩次攪拌之間等待2分鐘。液體和固體成分的比例取決於食譜，以便正確攪拌。冰塊可以在不加水的情況下破碎（冰塊邊長為2厘米）。如果您的設備無法運作，請檢查它是否正確連接到電源，電源線是否完好，以及刀片底座是否與攪拌杯組裝在一起。如果設備過熱，請拔掉插頭，讓設備冷卻至室溫。您的設備仍然無法運作嗎？請聯繫授權服務中心（請參見服務手冊）。

MS : *Tunggu selama 2 minit antara dua sesi pengadunan. Peratusan bahan cecair dan pepejal yang membolehkan pengadunan yang betul bergantung pada resipi. Ais boleh dihancurkan tanpa tampahan air (ketulan ais yang berukuran 2cm). Jika pengadun anda tidak berfungsi, semak bahawa ia disambungkan dengan betul pada sumber kuasa, kord kuasa dalam keadaan baik dan pemegang bilah dipasang dengan botol. Jika pengadun menjadi terlalu panas, cabut plag dan biarkan pengadun sejuk hingga suhu bilik. Pengadun anda masih tidak berfungsi? Hubungi pusat servis yang diluluskan (lihat buku panduan servis).

