



Mix & Move Blender


EN : Read safety instructions and booklet carefully before using for the first time.



1 Unboxing



1. Unscrew the bottle (B,C) from the motor unit, unscrew the blade unit (B), rinse the items under running water.




2. The motor unit (A) must not be placed under water.


2 First use




3-4. Fill the bottle (C) with your solid or liquid ingredients, be careful not to exceed the maximum level (600ml). We recommend to add a little quantity of liquid to enable proper blending




5. Screw the blade unit (B) clockwise onto the bottle (C)



6. Place the bottle (B,C) on the motor unit (A) and turn clockwise to lock it




7. Plug in to the mains




8. Press the start button (E) for 30 seconds maximum.
*Wait for 2 min between each blending sessions.


3 Warning




9. Do not operate the product with empty bottle



10. Do not insert whole/uncut ingredients



11. Do not exceed the maximum of 5 20mm ice cubes



12. When the blending session is over, gently unlock the bottle by unscrewing it anti-clockwise to remove it.
Your preparation is ready to enjoy!

We recommend to add some liquid to enable correct blending. The ratio of liquid and solid ingredients depends on the recipe.

You can crush ice cubes (up to 2 cm in size) without adding water. If your appliance isn't working, make sure it's properly plugged in, the power cord is undamaged, and the blade holder is correctly attached to the bottle. If the appliance overheats, unplug and let the appliance cool down to room temperature. Your appliance still does not work? Contact an approved service centre (see the service booklet).

			
	✗	✗	✓
	✓	✓	✓
	✓	✗	✗



Warning: Do not process hot liquids (over 70°C/158°F) in the on-the-go bottle.