

Rowenta®




THANK YOU FOR BUYING PURE POP!

GRACIAS POR COMPRAR PURE POP
GRAZIE PER AVER ACQUISTATO PURE POP
MERCI D'AVOIR ACHETÉ PURE POP

REMOVE CREASES... EASILY

ELIMINA LAS ARRUGAS... FÁCILMENTE
RIMUOVI LE PIEGHE... CON FACILITÀ
RETIRE LES PLIS ... FACILEMENT

1



FILL WATERTANK

LLENA EL DEPÓSITO DE AGUA
RIEMPIRE IL SERBATOIO DELL'ACQUA
REMPLIR LE RÉSERVOIR

2



SWITCH ON, WAIT 15s

ENCENDER, ESPERAR 15SEC
ACCENDERE, ATTENDERE 15SEC
ALLUMER, ATTENDRE 15SEC


3



& STEAM...

Y PLANCHA...
E STIRARE...
& DÉFROISSER...

4



... IN ANY WAY

... COMO QUIERAS
... IN QUALSIASI MODO
... DANS TOUTES LES DIRECTIONS

EXCLUSIVE REVERSIBLE PAD

CABEZAL REVERSIBLE EXCLUSIVO - ESCLUSIVA SPAZZOLA REVERSIBILE
PAD REVERSIBLE EXCLUSIF

VELVET SIDE...

LADO DE TERCIOPELO... - LATO IN VELLUTO...
CÔTÉ VELOURS...

1



STEAM WITH NO DAMAGE

PLANCHAR SIN RIESGOS
PER UNA STIRATURA SENZA DANNI
POUR DÉFROISSER SANS ABIMER

MICROFIBER SIDE

LADO PARA QUITAR POLVOS - LATO CON POLVERE
CÔTÉ ANTI-POUSSIÈRE

2



TO REMOVE DUST

ELIMINAR EL POLVO
PER RIMUOVERE LA POLVERE
POUR RETIER LA POUSSIÈRE

HOW TO USE?

¿CÓMO UTILIZARLA?
COME SI USA?
COMMENT UTILISER?

