



Guide de démarrage

1 Je déclare ma balance


A la première utilisation de votre

- Sélectionnez depuis votre écran d'accueil : « Paramètres » → « Mes accessoires »
- Sélectionnez « oui » dans l'écran qui apparaît



2 Je connecte ma balance à mon Cookeo.

- Lorsque vous sélectionnez « peser », lors d'une recette, l'appareil recherche la balance et le logo clignote
- Lorsque la balance est connectée, le logo reste fixe



3 Je pèse mes aliments

Vous pouvez accéder à la fonction pesage :



- Depuis la checklist d'une recette
- Depuis le pas à pas d'une recette
- Depuis la fonction dans mon frigo

! Avant de peser vos aliments, assurez-vous que votre balance est allumée.

DEPUIS LA CHECKLIST D'INGRÉDIENTS

1

- Choisissez votre recette
- Accédez à la checklist

DEPUIS LE PAS À PAS D'UNE RECETTE

1

Go

- Démarrez votre recette
- A chaque étape vous pouvez sélectionner le bouton « ingrédient »

^ Ingrédients

Checklist d'ingrédients

Pesée disponible Pesée indisponible

2

Choisissez votre ingrédient à peser dans la liste

3

Pour connecter votre balance, allumez la ou cliquez sur OK

4

La jauge à l'écran vous indique la quantité cible

OK OR Go

Après avoir pesé tous vos ingrédients, démarrez votre recette ou passez à l'étape suivante.

! Si la balance s'éteint pendant une recette, rallumez la et relancez la connexion.

DEPUIS LA FONCTION DANS MON FRIGO

1

Saisissez les ingrédients disponibles dans votre frigo

2

Sélectionnez vos ingrédients

3

Sélectionnez la fonction de pesage

D

4

Pour connecter votre balance, allumez la ou cliquez sur OK

5

Pesez vos ingrédients et appuyez sur OK

6

Choisissez votre recette


Quick Start Guide



1 Identify your weighting scale


When using your product for the first time:

- Select "Settings" from your home screen
- In "My accessories" select "yes" in the screen



2 Connect your Cookeo to your scale

- When you select "weigh", the device searches for the scale and the flashes
- When the scale is connected, the remains fixed



3 Weigh your ingredients

You can access the weighing function:

- From a recipe's checklist
- From a recipe's step by step
- From the "In my fridge" function



Before weighing your food, make sure your scale is turned on.



FROM A RECIPE'S CHECKLIST

FROM A RECIPE'S STEP BY STEP

1

- Choose your recipe
- Go to the checklist

1

Go

- Start your recipe
- In each step you can select the "ingredient" button

Ingredients

Ingredient checklist

Weighing function available Weighing function not available

2

Choose the ingredient you want to weigh from the list

3

To connect your scale, switch it on or press OK

4

The screen indicates the targeted quantity

OK OR **Go**

After weighing all of your ingredients, start your recipe or go to the next step

If the scale turns off during a recipe, turn it back on and restart the connection.



FROM THE "IN MY FRIDGE" FUNCTION

1

Enter the available ingredients in your fridge

2

Select your ingredients

3

Select the weighing function

D

4

To connect your scale, switch it on or press OK

5

Weigh your ingredients and press OK

6

Choose your recipe