

FR: Balance de cuisine / **EN:** Kitchen scale /
NL: Keukenweegschaal / **DE:** Küchenwaage /
IT: Bilancia da cucina / **ES:** Báscula de cocina /
PT: Balança de cozinha / **EL:** Ζυγαριά κουζίνας /
TR: Mutfak tartısı / **DA:** Køkkenvægt /
FI: Keittiövaaka / **RU:** Кухонные весы /
UK: Ваги кухонні / **PL:** Waga kuchenna /
CS: Kuchyňská váha / **HU:** Konyhai mérleg /
SK: Kuchynská váha / **RO:** Cântar de bucătărie /
SR: Kuhinjska vaga / **SL:** Kuhinjska tehtnica /
HR: Kuhinjska vaga / **BG:** Кухненска везна /
AR: نازيم خيطملا / **ET:** Köögikaal /
LV: Virtuves svāri / **LT:** Virtuvės svarstyklės

Tefal®



Simply 10 BC80xx


Instruction manual – Notice d'utilisation – Gebruiksaanwijzing – Bedienungsanleitung – Manuale di istruzioni – Manual de instrucciones – Manual de instruções – Εγχειρίδιο οδηγιών – Kullanma kilavuzu – Instrukcja obsługi – Uživatelská příručka – Használati útmutató – Návod na použitie – Manual de instrucțiuni – Uputstvo za upotrebu – Upute za uporabu – Ръководство с инструкции – Руководство по эксплуатации – Príročník z navodili – Посібник з експлуатації

ON





To start
Press 2 sec

OFF



Tare



unit

